

Guidance: Disinfecting Equipment Cab Contact Surfaces

Applies To: Transport Drivers, Yard/Utility Personnel, Field Service Technicians

Prior to touching/loading or operating equipment, disinfect equipment cab contact surfaces as follows:

Scope of Frequently Touched Contact Surfaces to Disinfect:

Contact Area	Preferred Cleaning Method/Product
Cab Door, Door Edges, and Grab Handles	Spray Nine Disinfectant
Seats, Armrests and Belt Buckles	Spray Nine Disinfectant + Seat Covers
Exposed Dash Surfaces	Spray Nine Disinfectant
Seat Adjustment Knobs	Spray Nine Disinfectant
Cup holders	Spray Nine Disinfectant
Fire Extinguishers	Spray Nine Disinfectant
Joysticks or Shift Levers	Disinfecting Wipes
Displays & Consoles	Disinfecting Wipes
HVAC Louvers & Switches	Disinfecting Wipes
Radio Controls	Disinfecting Wipes

Cleaning & Disinfection Guidelines:

1. Use appropriate PPE such as non-sterile disposable gloves prior to touching any contact surface or handling any cleaning and disinfecting solutions. Gloves and wipes are available through Parts. Never wash or reuse gloves. Eye protection, such as a face shield or goggles, may be required if splashing is expected.
2. Turn Machine OFF and insure all hvac/ventilation systems are OFF.
3. Follow manufacturer's disinfection guidelines (when conditions allow, clean first with soap and water if dirty, apply disinfectant & allow for recommended working time, wipe clean/remove residue)
4. Clean and disinfect touch/contact surfaces in the order noted above using the recommended or comparable product.
5. Spray fabric cab seats lightly with Spray Nine (use mist setting), wait 30 seconds and apply a seat cover prior to occupying the seat.
6. Disinfectants should be EPA approved, use bleach (1:100 ratio) only when preferred disinfectants are not available **and do not spray on fabric seats.**
7. Do not mix cleaning and sanitizing chemicals.
8. Do not use compressed air as a method for cleaning
9. Once disinfection of all touch surfaces is complete, tie a 24" section of survey flagging tape to the door handle as an identifier for downstream operations.

When in doubt: Spray the inside touchpoints of the cab with Spray Nine, let sit for 30 secs and wipe clean. Spray all outside hold handles with Spray Nine and let sit for 30 secs and wipe clean.